

DO NOT REMOVE

Northwestern | SCHOOL OF PROFESSIONAL STUDIES

SPS Lectern Instructions

SYSTEM POWER ON

1. Touch Crestron TouchScreen to power on system

A. LECTERN COMPUTER (RESIDENT PC)

1. Select "Resident PC"
2. If the computer is not on, the tower is located behind lectern cabinet door

B. LAPTOP

1. Select "Laptop"
2. Connect using the VGA cable provided
3. Select appropriate connector from source menu if it is not highlighted in blue

C. DVD

1. Select DVD
2. Open DVD player by pressing eject button on touchpad
3. Use the controls on the Creston touchpad to play disc and navigate menus

SHUTTING DOWN THE SYSTEM

1. Press the red shutdown button on touch screen and press the red "Shutdown" button on the screen when prompted for the "System Off Confirmation"

If you need any assistance, please dial SPS Helpdesk 1-312-503-3333 or On-Campus x3-3333