

Working with little ROs for syrup production
Stephen Childs, New York State Maple Specialist

One of the biggest drawbacks of making maple syrup for a back yarder or small maple producer is the time it takes to boil the sap into syrup. The idea of using a small reverse osmosis unit to assist with the syrup making is very interesting to many small maple producers. There are many little reverse osmosis systems available for water purification in households or for small commercial applications. These can be purchased from a number of big box stores, home improvement stores or on line. These RO units can be used to remove water from sap to speed up the concentration and syrup boiling process. To make a small RO unit work you must first get the sap under pressure using a pump, typically a shallow well pump. About 9 years ago I started experimenting with small reverse osmosis units to try and cut down on the amount of boiling time needed to make my family maple syrup. I started with a GE Merlin that was rated to deliver 30 gallons of pure water per hour when operated at about 60 psi. That rating is for when purifying permeate from water. When you are removing water from maple sap the permeate removal rate is reduced by 6x or I was removing between 4.5 and 5 gallons per hour. This was still a huge benefit for reducing the time of boiling my 25 taps on my 2' x 4' wood fired flat pan from about 8 hours per run to 4 hours. It would sweeten the sap from about 2% up to between 4 and 5%. The investment was about \$360 for the RO unit and I already had a shallow well pump that I used to pressurize the sap to about 55 psi and had to purchase a pre-filter canister. Though this system reduced my wood use by about 50% the primary benefit was the reduction in boiling time with no identifiable change in the taste or quality of maple syrup. In the off season the membranes were stored in the unit with permeate created by the unit. I used this unit for 4 years and by the fourth year notice a slight reduction in performance. To keep the pump from continually turning on and off while feeding the membrane and to maximize the pressure the pressure switch on the pump had to be set at maximum. The 6x reduction in capacity seems to be universal when processing sap vs. processing water with any unit set up and rated for water purification. So a home RO rated for 50 gallons per day would remove about 2 gallons per hour with water or would take about 1/3 of a gallon of water out of your sap per hour. That would be fine for someone with 2 or 3 taps. A larger unit that claims 240 gallons of water purified per day should take out about 10 gallons per hour from water but only about one and a half gallon of water from sap. That should be good for someone with up to 5 to 12 taps. With these water purification units you must remove the carbon filter as it will remove sugar and many other things you normally want in syrup.

Like any normal maple producer once the small RO was working well and syrup was more efficient to make, I annually added more taps so after using the Merlin for four years it was time to go bigger. I had a larger RO unit come available that had a higher pressure option using a small Procon pump on a half horse power electric motor and one 2.5" by 21" membrane. To this unit I added two more 2.5 by 21" membranes to boost the capacity to handle my now 70 taps. This unit operated at 250 psi, would remove about 15 gallons of permeate per hour and

could bring the sap up to 12% sugar if given enough time. So boiling for 70 taps was still taking about 4 hours of boiling time per run only with much greater yield. I continued to use the shallow well pump to feed this unit. I found that as the sap became sweeter the water removal rate would gradually be reduced. I found the best way to keep the production high was to process the sap in 15 gallon batches. So I would hook the RO to a 15 gallon jug of sap and run the concentrate back into the sap jug until the sap reached 10 to 12% at which time the permeate removal would be down to about 8 gallons per hour. The concentrated sap would then head to the boiler. As soon as we started on the next jug of 2% sap it would rinse out sugar build up in the membrane and go back to the full capacity of 15 gallons per hour. Both of the units above were used in the USDA Forest Farming youtube videos. Unfortunately the three membrane RO made the middle sized RO in the videos look much more complicated than it need to be creating lots of inquiries. It was nice that the shorter membranes were easier to transport to maple programs for demonstrations. It seems the 40" membranes and pressure vessels are more standard production than the 14" or 21" alternatives so they are much more economical to purchase for the amount of output. I had the three membranes hooked up in parallel to get the most water removed per hour. If they were hooked in series less water would be removed per hour but the sap could be much sweeter in one pass. For the off season I would store these membranes in holders made from PVC pipe that would be filled with permeate and a screw tight lid sealing the liquid and membrane in.

It was at this point that I began to gain friends. Friends who would show up at my garage with a 50 gallon barrel of sap or more and we would RO that down to about 15 gallons in about 2 and a half hours but these visits would save them between 8 and 20 hours of boiling time each time the sap ran. But the desire for something bigger was growing. The question of how to make a simple RO that would be most useful for maple operations of 300 to 500 taps lead to the next experiment. The fact that each year in the maple industry some percentage of maple producers are updating their 8" by 40" membranes that have lost some percentage of capacity seemed like it could be a low cost source for operations that don't need that maximum capacity. Breezy Maple Farm was updating some of their membranes and provided one for our testing. A 8" by 40" Codeline fiberglass pressure vessel was purchased on line along with a 330 gallon per hour Procon pump. This pump was connected using a cone connection to a standard shaft 1 horse motor that I already owned. This system operated at 250 psi and would remove about 300 gallons of permeate per hour. Total cost of materials was about \$1150. This performed with great efficiency but had a couple of unexpected issues. At first the pump would run but nothing happened, even when well primed. Turned out the motor was running backwards and needed to be rewired. The bolts in the motor were too short to connect to the cone so they had to be replaced with threaded rod and there was enough vibration in the cone to pump connection that it would wear out the rubber in the motor to pump coupling every couple of weeks. The clamp style connection between a motor and pump seem like a much better system. Here again I used the feed pump in addition to the higher pressure pump. Some are not using the feed pump, especially if the sap is slightly elevated over the pump so

that it can help with priming. This eliminates the cost of the feed pump. I've run them both ways but I get less chatter in the high pressure pump when I use the feed pump but performance seems equal. This system had more capacity than I need and sometimes I had trouble having enough permeate to give the 8" membrane the rinsing it should have following use.

The next year I tried a 4" by 21" membrane with the 330 gallon Procon pump. This unit did not put out as much as I expected. I had heard that it could do about 60 gallons per hour at 250 psi but I was usually getting about 45 of permeate per hour. Still great for my 70 taps and friends but when you look at the price of the 21" membrane and pressure vessel it is not that much less than a 4" by 40" which will have twice the performance. So the last year of making maple syrup at home we tried a 4" by 40" with the 330 gallons per hour pump and it performed very well delivering 80 to 100 gallons per hour of permeate.

The reason I felt it necessary to put this information together is the over whelming response we have had to the little RO youtube videos. The USDA wanted some Forest Farming Videos so they sent a crew to tape and record some presentations which went on line a little over two years ago. I figured there were likely a couple of hundred people who would be interested in making their own little RO. There are five videos on youtube talking about RO and covering the three different sizes I had experimented with at that time. As I checked last week they combined had over 60,000 views and hundreds of people have emailed questions about some aspect about building a little RO. If you are interested go to youtube.com and type in Cornell Reverse Osmosis and they will pop up. I hope this information will help answer many of people's questions so they don't have to try to track me down. If you are not at all mechanically inclined making your own RO is probably not the best idea. They are becoming more available at more reasonable prices than ever before. Buying one can save significant aggravation. If you are a do it yourselfer, this is a reasonable project to put one together. Some of little ROs from this project are now assisting with concentration of sap at the Cornell Arnot Forest.

Here are a few details that should help

The Merlin is no longer available.

Flush the RO filters with all the permeate you can save after every use. Do not use chlorinated water in your RO at any time. Store the membranes in pure permeate in the off season in your pressure vessel or make an air tight holder out of PVC pipe. There are preservatives and soap available for membranes if you need them. Follow suppliers' instructions and store where children cannot access.

The pressure in the RO is controlled by a valve on the exit end of the membrane on the concentrate line. Permeate comes out of the center of the membrane on both ends, you can

block one end so all the water come out one line. The concentrate goes in one end and out the other at the outside fittings by the rings of the membrane. Most small ROs without internal recirculation should send the concentrate back to the sap tank. Concentrate in batches.

Flow meters can be handy but you can get a quick measure by just putting the permeate line in a 5 gallon bucket and measuring how long it takes to fill it. After a few times you get pretty good at seeing when you are getting a great flow and when it is slowing down. I get excellent results with my 4x40 with a 3/4 hp pump and a 330 gallons per hour pump. If you get a much smaller pump, say a 150 gph, you get less flow over the membrane at a given pressure which allows the sugar to build up on the membrane and reduce its capacity. The membrane is like a fine screen and the more flow pushing the sugar along the longer it stays clean and functioning. You want a pump that has at least 50% more capacity than the rated capacity of the membrane and more is not a problem.

Change or clean your pre-filter often

Supplies are available in many places. I have used maple dealers, amazon.com, ebay.com, americanro.com, altanticro.com, freshwatersystems.com, nextgenmaple.com and Deer Run Maple plus there are many more.

A sap refractometer is very helpful when working with an RO as it can give you sugar contents in seconds and harder to break than a hydrometer.

There are many membranes available, I tend to pick the ones with the highest rating for the price.

Starting at the sap tank here the suggested parts in order: A foot valve, a line to either the feed pump(a valve just after the feed pump can cut down on the need to re-prime the pump so often, shut it when moving the line from one tank to another) or the pre-filter, from the pre-filter a line to the high pressure pump, a line from the high pressure pump to the outside fitting of the pressure vessel, a pressure vessel with a membrane inside, a concentrate line from the outside fitting on the exit end of the membrane that goes back to the sap tank or to a tank suppling the boiler, and a line from the center fitting on the pressure vessel to a tank for storing permeate.

A special thanks to Next Generation Maple and Deer Run Maple for all the help and encouragement with this project. Connected are some photos of little ROs that people have built.







